

HP DeskJet 2130 series

Product Number: F5S31B

11. SN = CN78F470170G5Z
12. PER = 065Z
13. ID = 28198
14. FW = WIP1FN1532AR PATCH = 0
15. ACC = NONE
16. PX = 8
17. BAR = 0000001b
21. PC = 2680
22. FB = 0/0
23. MS = NADA
24. ASIC = 1,1.1
25. RX = 03,050,0000
26. RC = 29269

31. TRAIL = 0
32. NO PK = 108
33. EX PK = 0
34. PJ = 8
35. CS = 3
36. SS = 0
41. Code1 = 00000000, Page = 0
42. Code2 = 00000000, Page = 0
43. Code3 = 00000000, Page = 0
44. Code4 = 00000000, Page = 0
45. Code5 = 00000000, Page = 0

E

F

E

F

51. TYPE = 1
52. ID = 0000-0000-0000-0000
53. PX = 0
54. HP = 3
55. USE = 0
56. STAT = 0
57. 91
58. IDH = 0000-0000-0000-0000
59. SPOT = 0
71. INS CMY = 4

61. TYPE = 0
62. ID = 288A-1005-5040-4DAB
63. PX = 8
64. HP = 1
65. USE = 0
66. STAT = 0
67. 100
68. IDH = 0005-0000-19A4-5900
72. INS K = 7

100. System Events

CS	MHS
66184 = 28132	75243 = 6
75241 = 28138	75209 = 129
75103 = 0	75040 = 0
75242 = 0	75245 = 0
75244 = 0	74901 = 6

PHS
70122 = 1162
70123 = 127
65848 = 1741992
65847 = 1233875